AQUATICUS1.0 Checklist

Mohamed Saad Ibn Seddik

07/19/2016

1 Shoreside Checklist

Main Bullet Radio plugged to POE
POE for Bullet is powered
Antenna is outside and has clear view of the field
A shoreside computer is connected to the network and has an IP address
Shoreside computer is running latest version of MOOS-IvP (svn up and build) $$
Shoreside computer is running latest version of MOOS-IvP-AQUATICUS (svn up and build)
Perform radio check with handheld radios

2 MOKAI Checklist

Check fuel level and oil maintenance on Vehicle
Power on main computer, login
Check for main computer battery level
Main computer is running latest version of MOOS-IvP (svn up and build)
Main computer is running latest version of MOOS-IvP-AQUATICUS (svn up and build) $$
Check for Bullet battery level
Verify Wi-FI is turned off on main computer
Verify Ethernet is plugged into the Bullet
Verify Ethernet is plugged into main computer
Main computer has an IP address
Verify Bullet is connected and has power (at least 3 LEDs are turned on)
Verify GPS is plugged into main computer
Verify Mic (red) and Audio Output (green) cables are plugged into main computer $$
Check that audio source is properly setup in main computer
Verify audio cables plugged into headset
Verify radio is plugged into headset
Perform a radio check
Check user wearing life jacket
Check safety line is attached to subject

3 M200 Checklist

Inspect front seat lid is secure in position and side cables are tight
Check battery level of M200
Power on vehicle and wait until flashes are double and steady
Check battery level PABLO box
Power PABLO box by plugging power cable and screw water-tight connection
Plug and secure Ethernet cable from PABLO box to front-seat.
Secure PABLO box area by placing the lid back in position
From remote computer, check that both front seat and PABLO box are responding to pings $$
PABLO is running latest version of MOOS-IvP (svn up and build)
PABLO is running latest version of MOOS-IvP-AQUATICUS (svn up and build)